

Sprężarki FRASCOLD - modele tłokowe

2 CYLINDRY	A	A054Y	A055Y	A075Y	A076Y	A16Y	A17Y	A157Y	A158Y					
	B	B159Y	B1510Y	B210Y										
	B.1	B159.1Y	B1510.1Y	B210.1Y										
	D	D213Y	D215Y	D313Y	D315Y	D316Y	D318Y	D319Y	D416Y	D418Y				
	D.1	D211.1Y	D213.1Y	D215.1Y	D313.1Y	D315.1Y	D316.1Y	D318.1Y	D319.1Y	D416.1Y	D418.1Y	D419.1Y		
	F	F416Y	F419Y	F421Y	F424Y	F519Y	F521Y	F524Y	F525Y	F528Y	F725Y	F728Y		
	F.1	F416.1Y	F419.1Y	F424.1Y	F519.1Y	F524.1Y								
4 CYLINDRY	Q	Q419Y	Q421Y	Q425Y	Q519Y	Q521Y	Q525Y	Q528Y	Q533Y	Q725Y	Q728Y	Q733Y		
	Q.1	Q419.1Y	Q421.1Y	Q424.1Y	Q425.1Y	Q519.1Y	Q521.1Y	Q524.1Y	Q525.1Y	Q528.1Y	Q533.1Y	Q725.1Y	Q728.1Y	Q733.1Y
	S	S533Y	S733Y	S739Y	S1039Y	S1051Y	S1551Y	S1556Y	S2056Y					
6 CYLINDRÓW	Z	Z25106Y	Z30126Y	Z35106Y	Z40126Y	Z40154Y	Z50154Y							
	W	W40142Y	W40168Y	W50168Y	W50187Y	W60187Y	W60206Y	W70206Y	W70228Y	W75228Y	W75240Y	W80240Y		
8 CYLINDRÓW	W	W40142Y	W40168Y	W50168Y	W50187Y	W60187Y	W60206Y	W70206Y	W70228Y	W75228Y	W75240Y	W80240Y		